



**POLICIES AND PROCEDURES MANUAL**

System       Department

**Supersedes:**

Section: **Doffing PPE with PAPR (Biological Protective Suit and Powered Air Purifying Respirator Checklist)**  
Subject: **Checklist**  
Number: 1093 A  
Attachments:  
Date Effective: May 2006  
March 2007; March 2009; June 2010; March 2013, January 2015, October 2015, December 2017, September 2018  
Date Reviewed: 2017, September 2018

Upon NBU Activation create a poster to hang in the doffing area(s) that lists the order in which PPE shall be removed. Always perform hand hygiene and don new gloves after touching contaminated items.

1. Disposable boots-remove in room
2. PAPR Belt with motor and tubing
3. DP to clean motor and tubing
4. Tape and long cuff purple exam gloves
5. DP to roll up outer hood cape, open zipper flap and lower zipper
6. HCW pull suit sleeves over hands, then shrugs/pulls suit towards feet, shuffling out of suit but remain standing on suit
7. DP to turn off PAPR, disconnect tubing from motor and cap
8. PAPR hood
9. Step to clean area and remove clear boot liners

**Department Approval**

Signed | s |: Kate Boulter  
Title: Nurse Manager  
Department: NBU

**Administrative Approval**

Signed | s |: Michele Schwedhelm  
Title: Executive Director